

**HOMTOM**

# HT7-Pro User Guide

Read this guide carefully before using your smartphone.

## 1 ICONS

| Icon                                                                                | Description                                 | Icon                                                                                  | Description                            |
|-------------------------------------------------------------------------------------|---------------------------------------------|---------------------------------------------------------------------------------------|----------------------------------------|
|    | Indicate the intensity of network signals.  |    | The phone is playing a song.           |
|    | Show missed calls.                          |    | Show battery level.                    |
|    | Location by satellite.                      |    | Enable USB.                            |
|    | Receive a new message.                      |    | The access is blocked.                 |
|    | An application is being downloaded.         |    | Get connected to the wireless network. |
|  | The downloading is over.                    |  | Turn on the Bluetooth.                 |
|  | The alarm clock has been set and activated. |  | No SIM card is installed in the phone. |
|  | A call is in progress.                      |  | GPRS data connection is on.            |



## **2 FUNCTIONAL MENU**

### **2.1 Dialing**

When dialing, you can have a quick access to the call records, contacts and digit dial keyboard (used for manual dialing) by the menu key on the screen.

### **2.2 Browser**

The browser allows you to surf on the internet and browse the page just like on the computer. You can create on the phone a bookmark. You can have a quick access to your favorite sites on the main screen.

You could view web pages in longitudinal or transverse mode. The page rotates according to the rotation of the phone and automatically adjusts to fit the page.

### **2.3 Settings**

Bluetooth: Bluetooth can be turned on and off and settings are made.

Data usage: It makes you in full awareness of the usage of the information.

Select a mode and enter the customized setting-up, operational are vibration, volume, ring tones, notifications and key beep, etc.



Display: Customized setting-up of the phone luminance, wallpaper, the screen and screen time-out and font size is allowed.

Storage: The internal memory of the storage card and of the phone is shown.

Battery: The usage detail of the battery's shown.

Applications: View, manage and delete the applications on your phone.

Account: Set the synchronization of your phone account with your phone.

Location service: Set the service during the locating.

Security: Set unlocking pattern; lock the SIM card; set the SD card.

Language & input: Select a language and input method.

Backup & reset: Reset DRM and restore factory settings to clear all personal data on your phone.

Date & time: Set current time and date.

Schedule power on/off: set the time to turn on or off your phone.

Accessibility: Some auxiliary functions can be set.

## **2.4 Clock**

### ■ Alarms

Your phone provides many groups of alarm clocks. Select one of them to edit and customize alarm clock.

### ■ World Time

You can set a different time zone.



- Stopwatch  
Single time you can also record multiple times.
- Timer  
You can turn the dial to set down time.

## **2.5 Camera**

Your phone provides the camera and video recorder features. Wherever you go, you can take high-resolution photos and videos. It also supports advanced camera features such as face Defection, panorama shooting, high dynamic range and zero delay shutter, which can also be customized.

## **2.6 Notification Menu**

Slide and pull down menu on the main interface, you can see the message notice and choose whether to turn on or off WIFI, Bluetooth, GPS, off-line mode. In the data connection, the current SIM is available to make data connection of GPRS. Slide it around you can see the options of profile for your convenience.

## **2.7 theme**

Click on the theme of your mobile phone to choose your favorite theme, you can also set the local picture as wallpaper.



### 3 FAQs and Solutions

If you have any questions about the phone, please find the solutions from the table below.

| FAQs                 | Causes                                                                                                                                                  | Solutions                                                                 |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| Poor reception       | When you use your phone at poor reception areas, for example, near high rise buildings or base rooms, the radio wave cannot be transmitted effectively. | Avoid this as far as you can.                                             |
|                      | When you use your phone at network traffic congestion, such as working time and off-duty time, the congestion can result in poor reception.             | Avoid this as far as you can.                                             |
|                      | This is related to the distance to base station in question.                                                                                            | You may ask the network service provider to provide service coverage map. |
| Echoes or noises     | The trunk line of network is in bad condition. It is a regional problem.                                                                                | Hang off the call and dial again. Choose another better line.             |
|                      | In some areas, the call lines are in bad condition.                                                                                                     |                                                                           |
| Shorter standby time | The standby time is relevant to network settings.                                                                                                       | In poor reception areas, turn off your phone temporarily.                 |



|                                  |                                                                                                                                                               |                                                                          |
|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
|                                  | Replace the batteries                                                                                                                                         | Change with a new battery.                                               |
|                                  | When no signals are received, your phone will continue searching for base stations, thus consuming a large amount of battery power and reducing standby time. | Use your phone at strong signal areas or Turn off the phone temporarily. |
| Failed to turn on your phone     | The battery power is used up.                                                                                                                                 | Check the battery power level or charge the battery.                     |
| SIM card error                   | The SIM card is damaged.                                                                                                                                      | Contact your network service provider.                                   |
|                                  | The SIM card is not properly installed.                                                                                                                       | Ensure the SIM card is properly installed.                               |
|                                  | The metallic face of the SIM card is contaminated.                                                                                                            | Wipe the face with a clean cloth.                                        |
| Failed to connect to the network | The SIM card is invalid.                                                                                                                                      | Contact your network service provider.                                   |
|                                  | Beyond the GSM coverage.                                                                                                                                      | Consult the network service provider for service areas.                  |
|                                  | The signal is feeble.                                                                                                                                         | Retry at a stronger signal area.                                         |
| Failed to make a call            | The call barring feature is used.                                                                                                                             | Cancel the call barring settings.                                        |
|                                  | The fixed dialing number feature is used.                                                                                                                     | Cancel the fixed dialing number settings.                                |



|                                      |                                                                                              |                                               |
|--------------------------------------|----------------------------------------------------------------------------------------------|-----------------------------------------------|
| PIN code error                       | Enter incorrect PIN codes for three times in succession.                                     | Contact your network service provider.        |
| Failed to charge the battery         | The battery or the charger is damaged.                                                       | Change a new battery or charger.              |
|                                      | Charge the battery when ambient temperature is lower than -10°C or above 55°C.               | Change the environment.                       |
|                                      | Poor connection.                                                                             | Check whether the plug is properly connected. |
| Failed to add contacts to phone book | The storage space of phone book is used up.                                                  | Delete some contacts from the phone book.     |
| Failed to set up some features       | Your network service provider does not provide the services, or you haven't subscribed them. | Contact your network service provider.        |



# SAFETY INFORMATION

Read this guide carefully before using your smartphone.

## [NL] Veiligheidsvoorschriften

**Om deze telefoon veilig te gebruiken. U wordt verzocht de veiligheidsinstructies aandachtig door te lezen :**

1. Kinderen : Wees extra voorzichtig met kinderen. Een mobiele telefoon bevat vele losse onderdelen, dus ben zeer voorzichtig wanneer een kind in contact komt met een mobiele telefoon. Het product bevat kleine onderdeeltjes die kunnen worden ingeslikt of die verstikking kunnen veroorzaken indien ingeslikt. Wanneer het apparaat is uitgerust met een camera of een flitser, moet u het niet te dicht bij de ogen van kinderen of dieren gebruiken.
2. Gehoor : Als u langdurig en met hoog volume naar muziek luistert met een lichtgewicht hoofdtelefoon of oortelefoon, kan dit uw gehoor beschadigen. Zorg ervoor dat u het volume verlaagt tot het strikte minimum wanneer u naar muziek of een gesprek luistert. Vermijd een hoog geluidsvolume gedurende lange tijd.
3. Rijden : Wees voorzichtig wanneer u rijdt. Rijden vereist een extreme en regelmatige aandacht om het risico van een ongeval zo veel mogelijk te beperken. Het gebruik van een mobiele telefoon kan de gebruiker afleiden en leiden tot een ongeval. De geldende wetten en lokale regelgevingen met betrekking tot de beperkingen op het gebruik van draadloze telefoon achter het stuur dienen strikt te worden gevolgd. Het is dus verboden om te telefoneren onder het rijden en het gebruik van een hands-free kit mag niet worden beschouwd als een oplossing. In het vliegtuig : Zet uw telefoon uit in het vliegtuig. Vergeet niet om uw telefoon uit te schakelen wanneer u zich in een vliegtuig bevindt (GsM + Bluetooth). Dit kan namelijk interferentie veroorzaken.
4. In het ziekenhuis : Zet uw telefoon uit in de buurt van medische apparatuur. Het is heel gevaarlijk om een telefoon aan te laten staan in de buurt van een medisch instrument. Dit kan interferentie veroorzaken met medische instrumenten. De instructies en waarschuwingen in ziekenhuizen en zorgcentra dienen daarom strikt te worden gevolgd. Vergeet niet om uw telefoon uit te schakelen in benzinestations. Gebruik het apparaat niet in een benzinestation in de buurt van brandstof. Het is gevaarlijk om uw telefoon te gebruiken in een professionele garage.
5. Elektronische implantaten en pacemakers : Personen met elektronische implantaten of een pacemaker moeten uit voorzorg de telefoon aan de tegengestelde zijde van het implantaat houden tijdens een gesprek. Als u merkt dat uw apparaat interferentie veroorzaakt met een pacemaker, zet u de telefoon onmiddellijk uit en neemt u contact op met de fabrikant van de pacemaker, om te vragen wat u moet doen.



6. Brandgevaar : Laat het apparaat niet in de buurt van warmtebronnen zoals een radiator of kachel. Laat uw telefoon niet laden in de buurt van brandbare materialen (het brandgevaar is reëel).
7. Contact met vloeistoffen : Zorg dat de telefoon niet in aanraking komt met vloeistoffen of met natte handen. Waterschade kan onherstelbaar zijn.
8. Gebruik alleen accessoires die zijn goedgekeurd door HOMTOM. Het gebruik van niet-goedgekeurde accessoires kan uw telefoon beschadigen of risico's veroorzaken.
9. De batterijen en de laders niet vernietigen : Nooit een beschadigde lader of batterij gebruiken. De batterijen niet in aanraking laten komen met magnetische objecten, omdat dit kortsluiting zou kunnen veroorzaken tussen de plus- en minpolen van uw batterijen en deze of de telefoon blijvend beschadigen. In het algemeen mogen de batterijen niet worden blootgesteld aan zeer lage of zeer hoge temperature (onder 0°C of hoger dan 45°C). Deze verschillen in temperatuur kunnen de autonomie en de levensduur van de batterijen verminderen.
10. Schokken of stoten : Gebruik en behandel uw telefoon met de grootst mogelijke zorg. Bescherm uw telefoon tegen schokken of stoten die het zouden kunnen beschadigen. sommige onderdelen van de telefoon zijn van glas en kunnen daarom breken door een val of een grote schok. Laat het apparaat niet vallen. Raak het scherm niet aan met een scherp voorwerp.
11. Elektrische ontlading : Probeer uw telefoon niet te demonteren, omdat dit een elektrische schok kan veroorzaken.
12. Onderhoud : Als u uw handset wilt schoonmaken, gebruikt u hiervoor een droge doek (geen oplosmiddelen zoals benzeen of alcohol).
13. Laad de telefoon op in een goed geventileerde plaats. Laad uw apparaat niet op als het zich op stof bevindt.
14. Wissen van magneetbanden : Plaats uw telefoon niet naast een creditcard, want dit kan gevolgen hebben voor de gegevens op magneetbanden.