



MeMO Pad

E-Manual

ASUS is devoted to creating environment-friendly products and packaging to safeguard consumers' health while minimizing the impact on the environment. The reduction of the number of the manual pages complies with the reduction of carbon emission.

For the detailed user manual and related information, refer to the user manual included in the MeMO Pad or visit the ASUS Support Site at <http://support.asus.com/>.

COPYRIGHT INFORMATION

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2013 ASUSTeK COMPUTER INC. All Rights Reserved.

LIMITATION OF LIABILITY

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

SERVICE AND SUPPORT

Visit our multi-language web site at <http://support.asus.com>

Contents

About this manual	6
Conventions used in this manual	7
Typography	7
Safety Precautions	8
Charging your batteries	8
Using your MeMO Pad.....	8
Airplane Precautions	8
Package contents	9
Chapter 1: Hardware Setup	
Getting to know your MeMO Pad	12
Front view	12
Rear view	13
Chapter 2: Using your MeMO Pad	
Setting up your MeMO Pad	18
Charging your MeMO Pad.....	18
Turning your MeMO Pad on	19
Gestures for the MeMO Pad	20
Connecting an HDMI-compliant display	23
Chapter 3: Working with Android®	
Starting up for the first time	26
Android® lock screen	26
Unlocking your device.....	26
Entering the camera mode	27
Entering Google Now	27
Home Screen	29
Screen views.....	30
Locking the screen orientation	31

Connecting to the world.....	31
Connecting to Wi-Fi networks	31
Using Bluetooth	32
Managing Apps	34
Creating app shortcuts.....	34
Viewing app info.....	34
Removing an app from the Home Screen.....	35
Creating app folder.....	36
Viewing apps under the Recents screen.....	37
Task Manager	39
File Manager	41
Accessing the internal storage	41
Accessing the external storage device	42
Customizing your contents.....	43
Settings.....	44
ASUS Quick Setting.....	45
Turning your MeMO Pad off	48
Putting your MeMO Pad to sleep.....	48
Chapter 4: Pre-installed Apps	
Featured pre-installed apps.....	50
Play Music.....	50
Camera	51
Gallery	52
Email	57
Gmail	59
Play Store	60
Maps	61
MyLibrary Lite.....	62
SuperNote.....	67
AudioWizard.....	72

App Locker	73
App Backup	76
Widgets	80
ASUS Battery	81

Appendices

Federal Communications Commission Statement	84
RF Exposure Information (SAR)	85
Canada, Industry Canada (IC) Notices.....	85
Canada, avis d'Industrie Canada (IC)	86
IC Warning Statement.....	86
EC Declaration of Conformity	87
Prevention of Hearing Loss.....	87
CE Mark Warning	88
RF Exposure information (SAR) - CE.....	89
Power Safety Requirement	89
ASUS Recycling/Takeback Services.....	89
Regional notice for Singapore	89
Coating notice	89
Proper disposal.....	90

About this manual

This manual provides information about the hardware and software features of your MeMO Pad, organized through the following chapters:

Chapter 1: Hardware Setup

This chapter details the hardware components of your MeMO Pad.

Chapter 2: Using your MeMO Pad

This chapter shows you how to use the different parts of your MeMO Pad.

Chapter 3: Working with Android®

This chapter provides an overview of using Android® in your MeMO Pad.

Chapter 4: Pre-installed Apps

This chapter features the pre-installed applications included with your MeMO Pad.

Appendices

This section includes notices and safety statements for your MeMO Pad.

Conventions used in this manual

To highlight key information in this manual, some texts are presented as follows::

IMPORTANT! This message contains vital information that must be followed to complete a task.

NOTE: This message contains additional information and tips that can help complete tasks.

WARNING! This message contains important information that must be followed to keep you safe while performing tasks and prevent damage to your MeMO Pad's data and components.

Typography

Bold = This indicates a menu or an item that must be selected.

Italic = This indicates sections that you can refer to in this manual.

Safety Precautions

Charging your batteries

Ensure to fully charge your battery pack before using your MeMO Pad in battery mode for extended periods. Remember that the power adapter charges the battery pack as long as it is plugged into an AC power source. Be aware that it takes much longer to charge the battery pack when the MeMO Pad is in use.

IMPORTANT! Do not leave the MeMO Pad connected to the power supply once it is fully charged. MeMO Pad is not designed to be left connected to the power supply for extended periods of time.

Using your MeMO Pad

This MeMO Pad should only be used in environments with ambient temperatures between 0°C (32°F) and 35°C (95°F).

Long time exposure to extremely high or low temperature may quickly deplete and shorten the battery life. To ensure the battery's optimal performance, ensure that it is exposed within the recommended environment temperature.

Airplane Precautions

Contact your airline provider to learn about related inflight services that can be used and restrictions that must be followed when using your MeMO Pad in-flight.

IMPORTANT! You can send your MeMO Pad through x-ray machines (used on items placed on conveyor belts), but do not expose them from magnetic detectors and wands.

Package contents



ASUS MeMO Pad




Power adapter



Micro USB cable



User manual



Warranty card

NOTES:


- If any of the items is damaged or missing, contact your retailer.
 - The bundled power adapter varies with country or region.
-

Chapter 1:

Hardware Setup

Getting to know your MeMO Pad

Front view




- 1 Touch screen panel**

The touch screen panel allows you to operate your MeMO Pad using the stylus or touch gestures.
- 2 Ambient light sensor**

The ambient light sensor detects the amount of ambient light in your environment. It allows the system to automatically adjust the brightness of the display depending on the ambient light condition.
- 3 Front camera**

This built-in 1.2-megapixel camera allows you to take pictures or record videos using your MeMO Pad.

Rear view



1 Speaker/Headset port

This port allows you to connect your MeMO Pad to amplified speakers or a headset.

IMPORTANT! This port does not support an external microphone.

2 Volume button

The volume button allows you to increase or decrease the volume level of your MeMO Pad.

3 Audio speakers

The built-in audio speakers allow you to hear audios straight from your MeMO Pad. Audio features are software controlled.

4 Rear camera

This built-in 5-megapixel camera allows you to take high-definition pictures or record high-definition videos using your MeMO Pad.

5 Power button

Press the power button for about two (2) seconds to turn your MeMO Pad on or wake it up from standby mode.

To turn your MeMO Pad off, press the power button for about two (2) seconds and when prompted, tap **Power Off** then tap **OK**.

To lock your MeMO Pad or put it to standby mode, press and quickly release the power button.

In the event that your MeMO Pad becomes unresponsive, press and hold the power button for about ten (10) seconds to force it to shut down.

IMPORTANT!

- When your MeMO Pad is inactive for fifteen (15) seconds, it will automatically go to standby mode.
 - Forcing the system to restart may result to data loss. We strongly recommend that you back up your data regularly.
-

6 Microphone

The built-in microphone can be used for video conferencing, voice narrations or simple audio recordings.

7 Micro USB 2.0 port

Use the micro USB (Universal Serial Bus) 2.0 to charge the battery pack or supply power to your MeMO Pad. This port also allows you to transfer data from your computer to your MeMO Pad and vice versa.

NOTE: When you connect your MeMO Pad to the USB port on your computer, your MeMO Pad will be charged only when it is in sleep mode (screen off) or powered off.

8 **Micro HDMI port**

This port is for a micro HDMI (High-Definition Multimedia Interface) connector and is HDCP compliant for HD DVD, Blu-ray and other protected content playback.

9 **MicroSD card slot**

The MeMO Pad comes with a built-in memory card reader slot that supports microSD, microSDHC and microSDXC card formats.

10 **Manual reset hole**

If the system becomes unresponsive, push inside the manual reset hole using a straightened paper clip to force-restart your MeMO Pad.


IMPORTANT! Forcing the system to restart may result to data loss. We strongly recommend that you back up your data regularly.

Chapter 2:

Using your MeMO Pad

Setting up your MeMO Pad

Charging your MeMO Pad



To charge your MeMO Pad:

- A** Connect the micro USB cable to the power adapter.
- B** Plug the micro USB connector into your MeMO Pad.
- C** Plug the power adapter into a grounded socket outlet.



Charge your MeMO Pad for eight (8) hours before using it in battery mode for the first time.

IMPORTANT!


- Use only the bundled power adapter and micro USB cable to charge your MeMO Pad. Using a different power adapter may damage your MeMO Pad.
 - Peel the protective film off from the power adapter and micro USB cable before charging the MeMO Pad to prevent risk or injury.
 - Ensure that you plug the power adapter to the correct socket outlet with the correct input rating. The output voltage of this adapter is DC 5V, 2A.
 - Do not leave the MeMO Pad connected to the power supply once it is fully charged. MeMO Pad is not designed to be left connected to the power supply for extended periods of time.
 - When using your MeMO Pad while plugged-in to a power outlet, the grounded power outlet must be near to the unit and easily accessible.
-

NOTES:

- Your MeMO Pad can be charged via the USB port on the computer only when it is in sleep mode (screen off) or powered off.
 - Charging through the USB port may take longer time to complete.
 - If your computer does not provide enough power for charging your MeMO Pad, charge your MeMO Pad via the grounded socket outlet instead.
-

Turning your MeMO Pad on

To turn your MeMO Pad on, press the power button for about two (2) seconds.



Gestures for the MeMO Pad

Using the touch screen panel, the following gestures can be done to navigate, interact with, and launch the exclusive features included with your MeMO Pad.

Drag/Tap and hold/Long press



- To move an app, tap and hold the app and drag it to a new location.
- To delete an app from the main screen, tap and hold the app and drag it up to the top side of the screen.
- To capture a screen image, tap and hold .

NOTE: To enable this setting, go to  > **ASUS Customized Setting** then tick **Capture screenshots by holding the Recent Apps Key.**

Tap/Touch



- Tap an app to launch it.
- In the File Manager app, tap to select and open a file.

Zoom out




Bring together your two fingers on the touch panel to zoom out an image in Gallery, Maps or Places.

Zoom in




Spread apart your two fingers on the touch panel to zoom in an image in Gallery, Maps or Places.

Swipe



Swipe your finger to the right or to the left on the touch panel display to switch between screens or to flip through the pages of an e-book or a gallery of images.

Connecting an HDMI-compliant display



To connect an HDMI-compliant display:

- A** Connect the micro HDMI connector to the micro HDMI port of your MeMO Pad.
- B** Plug the HDMI cable to the HDMI port of an HDMI-compliant display.

Chapter 3:

Working with Android®

Starting up for the first time

When you start your MeMO Pad for the first time, a series of screens appear to guide you in configuring the basic settings of your Android® operating system.

To start for the first time:

1. Turn your MeMO Pad on.
2. Choose a language, then tap ►.
3. Select an input method or keyboard format, then tap ►.
4. Select a wireless network to connect to the Internet, then tap **Next**. Otherwise, tap **Skip**.
5. Set the local date and time, then tap ►.
6. Follow the onscreen instructions to configure the following items:
 - Google Account
 - Google Settings and services
7. Tap ► to enter Home screen, then tap **OK**.

Android® lock screen

Unlocking your device

Tap and drag the lock icon to the unlocked icon.




Entering the camera mode

Tap and drag the lock icon to the camera icon.




Entering Google Now

Tap and drag the lock icon to Google icon.



Google Now

Google Now is your MeMO Pad's personal assistant, giving you instant updates on weather conditions, nearby restaurants, flight schedules, scheduled appointments, and other related information based from your web history, synced calendars and reminders.



Home Screen



Screen views

The built-in gravity sensor and gyroscope of your MeMO Pad enable automatic screen rotations depending on how you hold it. You can quickly switch between a landscape or portrait view by steering your MeMO Pad to the left or to the right, or tilting it horizontally or vertically.

Landscape view



Portrait view



Locking the screen orientation

By default, your MeMO Pad screen automatically changes its orientation from portrait mode to landscape mode or vice-versa, depending on the way you hold your device.

You can disable the auto-rotate screen function by following these steps:

1. Tap  on the top right corner of the Home Screen to open All Apps screen.
2. Tap  > **Accessibility** then tap **Auto-rotate screen** to deselect.

NOTE: You can also enable or disable this function from the ASUS Quick Settings. Refer to section **Settings** for more details.

Connecting to the world

Connecting to Wi-Fi networks

Wi-Fi wireless networking technology allows you to exchange data wirelessly over a network. To use Wi-Fi, enable the Wi-Fi feature in your MeMO Pad and connect to a wireless network. Some wireless networks are secured with a key or protected with digital certificates and requires additional steps to set up; others are open and you can easily connect to them.

NOTE: Turn Wi-Fi off when you are not using it to help save battery power.

To enable Wi-Fi and connect to a Wi-Fi network:

1. Tap  to go to the All Apps screen then tap .
2. Slide the Wi-Fi switch to ON. When enabled, your MeMO Pad scans for available Wi-Fi networks.
3. Tap a network name to connect to it. If the network is secured or protected, you are prompted to key in a password or key in other credentials.

NOTE: If your MeMO Pad finds a network that you have connected to previously, it automatically connects to it.

Using Bluetooth

Enabling or disabling Bluetooth in your device

Bluetooth is a wireless standard used for exchanging data over short distances. Bluetooth exists in many products such as smartphones, computers, tablet devices and headsets.

Bluetooth is very useful when transferring data between two or more devices that are near each other.

The first time you connect to a Bluetooth device, you must pair it with your MeMO Pad.

NOTE: Turn Bluetooth off when you are not using it to help save battery power.

To enable or disable Bluetooth in your MeMO Pad, you can do any of the following:

- Tap  to go to the All Apps screen then tap . Slide the Bluetooth switch to **ON**.
- Tap the Notification area to display **ASUS Quick Settings** panel then tap .

Pairing your MeMO Pad with a Bluetooth device

Before you can connect to a Bluetooth device, you must first pair your MeMO Pad to that device. The devices stay paired, unless you remove the paired connection between them.

To pair your MeMO Pad to a device:

1. Tap  to go to the All Apps screen then tap . Slide the Bluetooth switch to **ON**.
2. Tap **Bluetooth** to display all available Bluetooth devices within range.

NOTES:

- If the device you want to pair with is not in the list, ensure that its Bluetooth feature is turned ON and set as Discoverable.
 - See the technical documentation that came with the device to learn how to turn its Bluetooth ON and how to set it to discoverable.
-

3. If your MeMO Pad has finished scanning before your Bluetooth device is ready, tap **SEARCH FOR DEVICES**.
4. In the list of available devices, tap the Bluetooth device that you want to pair with. Follow the succeeding screen instructions to complete the pairing. If necessary, refer to the technical documentation that came with the device.

Connecting your MeMO Pad to a Bluetooth device

After you have paired your MeMO Pad to a Bluetooth device, you can easily reconnect to it manually, after it is back in range.

To connect to a Bluetooth device:

1. Tap  to go to the All Apps screen then tap . Slide the Bluetooth switch to **ON**.
2. In the list of PAIRED DEVICES, tap the name of the paired device.

Unpairing and configuring a Bluetooth device

To unpair or configure a Bluetooth device:

1. Tap  to go to the All Apps screen then tap . Slide the Bluetooth switch to **ON**.
2. Tap **Bluetooth** then tap  beside the connected Bluetooth device that you want to unpair or configure.
3. From Paired Bluetooth device screen, you can do any of the following:
 - Tap **Unpair** to unpair the device.
 - Tap **Rename** to rename the Bluetooth device.
 - Tap any of the listed profiles to enable or disable a profile.
4. Tap  to go back to previous screen.

Managing Apps

Creating app shortcuts


Get easy access to some of your favorite applications by creating app shortcuts on your Home Screen.

To create shortcuts:

1. Tap  to go to the All Apps screen.
2. From the All Apps screen, tap and hold the app's icon then drag it to the Home Screen.

Viewing app info

You can view the detailed app information while creating a shortcut for the app. While holding an app from the All Apps screen, the display switches to Home Screen and the App info will appear on the top of the Home Screen display. Drag the app to **App info** to display its detailed information.



Removing an app from the Home Screen

Free up space for new app shortcuts by removing existing app shortcuts on your Home Screen.

To remove app shortcuts:

1. Tap and hold an app until the **X Remove** appears on top of the screen.
2. Drag the app to **X Remove** to remove it from the Home Screen.



Creating app folder

You can create folders to organize shortcuts on your Home Screen.


To create an app folder:

1. On the Home Screen, tap and drag an app or shortcut onto another app until a black circle appears.

NOTES:

- The created folder is shown in a black circle.
 - You can add multiple apps in your folder.
-

2. Tap the folder then tap **Unnamed Folder** and key in a new folder name.



Viewing apps under the Recents screen

The Recents screen allows you to view a list of app shortcuts based from your recently launched apps. Using the Recents screen, you can easily go back to or switch between the apps you recently launched.

To access the Recents screen:

1. Tap  on the lower left corner of the Home Screen.
2. A list shows up to display all your recently launched apps. Tap on the app you want to launch.



To view a recent app's menu:

1. Tap and hold a recent app to display its menu.
2. To remove an app from the list, select **Remove from list**. To view its information, select **App info**.



NOTE: You can also remove a recent app from the list by swiping it to the left or right.

Task Manager

ASUS Task Manager displays a list of currently running utilities and applications, including their usages in percentages, on your MeMO Pad. You can also open and close the running apps individually or close all apps and utilities at once using the **One-click Clean** function.

To manage Task Manager:

1. Tap **■ ■ ■ ■** to go to the All Apps screen then tap **WIDGETS** to display the Widgets menu.
2. Tap and hold **ASUS Task Manager** to display the ASUS Task Manager box on the Home Screen.



3. Tap and hold the widget to display the sizing brackets. Drag the sizing bracket upward or downward to show the complete list of tasks.
4. Tap  beside the running app to close it. Tap **One-click Clean** to close all running apps at once.




File Manager

File Manager allows you to easily locate and manage your data either on the internal storage or the connected external storage devices.

Accessing the internal storage

To access the internal storage:

1. Tap  to go to the All Apps screen.
2. Tap  > **Internal Storage** on the left panel to view the contents of your MeMO Pad then tap an item to select. If a microSD card is inserted, tap **MicroSD** to view the contents of your microSD card.



3. Tap  to return to the root directory of My Storage.



Accessing the external storage device

To access the external storage device:

1. Tap  on the bottom right corner of the Home Screen to display the notification box.




2. Tap **Open** to display the contents of your microSD card. To unmount the microSD card from your MeMO Pad, tap **Unmount**.

IMPORTANT! Ensure to save your data stored in your microSD card before unmounting the microSD card from your MeMO Pad.

Customizing your contents

From File Manager, you can copy, cut, share and delete the contents of your device and the installed external storage device.

To customize a file or folder, tick the box beside the file or folder and the action bar appears on the upper right corner of the screen.



NOTES:

- The **SHARE** action will only appear if you select a file or files.
- You can also tick the file or folder then drag and drop it to your desired destination folder.

2. Tap the Notification area to display **ASUS Quick Settings** panel then tap .




ASUS Quick Setting

ASUS Quick Setting



ASUS Quick Setting Adjustment panel

Tap any of the following icons to enable or disable the function.




NOTES:

- **Balanced mode [Default mode]:** Balances the system's performance and power usage.
 - **Performance mode:** Maximizes the system's performance but consumes more battery power.
 - **Power saving mode:** Puts your device in energy-saving mode.
-

Notification panel

Notification panel appears under the Quick Setting panel for alerts or updates in apps, incoming e-mails and utility status.



NOTE: Swipe the notification to the right or to the left to remove the item from the list.

Turning your MeMO Pad off

You can shut down your MeMO Pad by doing either of the following:

- Press the power button for about two (2) seconds and when prompted, tap **Power Off** then tap **OK**.
- If your MeMO Tab is unresponsive, press and hold the power button for about ten (10) seconds until your MeMO Tab turns off.

IMPORTANT! Forcing the system to shut down may result to data loss. Ensure that you back up your data regularly.

Putting your MeMO Pad to sleep

To put your MeMO Pad to sleep, press the power button once.

Chapter 4:

Pre-installed Apps


Featured pre-installed apps

Play Music

Play Music app, an integrated interface for your music collection, allows you to play your saved music files stored internally or from an installed external storage device.

You can shuffle and play all music files randomly or flip to select an album for your listening pleasure.

On the Home Screen, tap  to play your music files.



NOTES:

The following audio and video codec are supported by your MeMO Pad:

- **Decoder**

Audio Codec: AAC LC/LTP, HE-AACv1(AAC+), HE-AACv2(enhanced AAC+), AMR-NB, AMR-WB, MP3, FLAC, MIDI, PCM/WAVE, Vorbis, WAV a-law/mu-law, WAV linear PCM, WMA 10, WMA Lossless, WMA Pro LBR

Video Codec: H.263, H.264, MPEG-4, VC-1/WMV, VP8

- **Encoder**

Audio Codec: AAC LC/LTP, AMR-NB, AMR-WB

Video Codec: H.263, H.264, MPEG-4

Camera

The Camera app allows you to take pictures and record videos using your MeMO Pad.

To launch the Camera app, tap  on the Home Screen.

NOTE: The pictures and video files are automatically saved to Gallery.

Camera mode



Video mode




Gallery

View images and play videos on your MeMO Pad using the Gallery app. This app also allows you to edit, share or delete image and video files stored in your MeMO Pad. From Gallery, you can display images in slideshow or tap to view the selected image or video file.


To launch Gallery, tap  on the Home Screen.

Gallery main screen



Sharing and deleting albums

To share an album, tap and hold an album until a tool bar appears on top of the screen. You can upload or share the selected albums online or delete them from your MeMO Pad.



Sharing, editing and deleting images

To share, edit or delete an image, tap to open an image then tap on the image to launch the tool bar on top of the screen.

Sharing images

To share an image:

1. From Gallery screen, open an album containing the image that you want to share.
2. Tap to select then tap  and select from the list of sharing apps.



To share multiple images:


1. From Gallery screen, open an album containing the images that you want to share.
2. Tap and hold one image then tap the other images.
3. Tap  then select from the list of sharing apps.



Editing an image

To edit an image:

1. From Gallery screen, open an album containing the image that you want to edit.
2. Tap an image to open then tap **⋮** > **Edit**.
3. Tap the editing tools to start editing.



Deleting images

To delete an image:

1. From the Gallery screen, open an album containing the image that you want to delete.
2. Tap an image to open then tap **🗑️**.
3. Tap **OK**.

To delete multiple images:


1. From Gallery screen, open an album containing the images that you want to delete.
2. Tap and hold one image then tap the other images.
3. Tap **🗑️** then tap **OK**.

Accessing Gallery widget

The Photo Gallery widget allows quick access to your favorite photos or albums right from the Home Screen.

To display Gallery Photo widget on the Home Screen:

1. Tap **■ ■ ■ ■** to display the All apps screen.
2. Tap **WIDGETS** tab to display the widgets menu.
3. Tap and hold **Photo Gallery** until the Gallery widget box moves to the Home Screen and displays the **Choose images** dialog box.
4. Choose an option from the **Choose images** dialog box that you want to place as a widget on the Home Screen.



Email

The Email app allows you to add POP3, IMAP and Exchange accounts so you can receive, create and browse e-mails right from your MeMO Pad.

IMPORTANT! You must be connected to the Internet so you can add e-mail accounts or send and receive e-mails from added accounts.

Setting up an e-mail account

To set up an e-mail account:

1. Tap  to display the All apps screen.
2. Tap  to launch the Email app.
3. From the Email app screen, key in your e-mail address and password then tap **Next**.


NOTE: Wait while your MeMO Pad automatically checks your incoming and outgoing mail server settings.



4. Configure the **Account options** and tap **Next**.




5. Key in an account name that you want to be displayed in the outgoing messages, then tap **Next** to log into your inbox.



Adding e-mail accounts

To add e-mail accounts:

1. Tap  to display the All apps screen.
2. Tap  then log in using the account.
3. Tap  > **Settings**. Tap **Add account** on the upper right corner of your screen.




Gmail

Using the Gmail app, you can create a new Gmail account or synchronize your existing Gmail account so that you can send, receive and browse e-mails right from your MeMO Pad. Enabling this app allows you to access other Google apps that may require a Google account, such as Play Store.

Setting up a Gmail account

To set up a Gmail account:

1. On the Home Screen, tap  .
2. Tap **Existing** and key in your existing Gmail account and password, then tap **Sign in**.



NOTES:

- Tap **New** if you do not own a Google account.
- When signing in, you have to wait while your MeMO Pad communicates with Google servers to setup your account.

3. Use your Google account to backup and restore your settings and data. Tap **Next** to sign in to your Gmail account.



IMPORTANT! If you have several e-mail accounts aside from Gmail, use Email app to set up and access all your e-mail accounts at the same time.

Play Store

Access lots of fun games and apps in the Play Store using your Google account.

IMPORTANT! You can only access Play Store by signing in to your Google account.

Accessing Play Store

To access Play Store:

1. On the Home Screen, tap  .
2. If you already have an existing Google account, tap **Existing** and key in your e-mail account and password. If you do not have an account, tap **New** and follow the on-screen instructions to create an account.
3. After signing in, you can start downloading apps from Play Store and install them in your MeMO Pad.



IMPORTANT! Download the latest version of Adobe Flash Player for Android® devices.

NOTES:

- You cannot restore the deleted apps, but you can log in with the same ID and download them again.
 - Some apps are free and some might charge you through a credit card.
-


Maps

Google Maps allows you to view and find places, establishments and get directions. It also allows you to check your current location and share the information with others.

Using Google Maps

To use Google Maps:

1. Tap  to display the All apps screen then tap .
2. Use the tool bar on top of the screen to customize your search.



MyLibrary Lite


MyLibrary Lite, an integrated interface for your book collections, allows you to place your purchased or downloaded e-books into bookshelves and sort them by author, title or date.

To launch MyLibrary Lite, tap  to display the All apps screen then tap . My Library Lite

IMPORTANT! You may need to install Adobe® Flash® Player to open some e-books. Download Adobe® Flash® Player before using MyLibrary Lite.


NOTE: MyLibrary Lite supports e-books in ePub, PDF and TXT formats.

MyLibrary Lite main screen




Reading your e-books

When you read an e-book, swipe your finger to the left to proceed to the next page or swipe your finger to the right to go back to the previous page.



Flipping a page

To move to the next page, swipe from right to left. To go back to previous page, swipe from left to right.



Placing a bookmark

The bookmark allows you to mark the pages of a book so that you can easily return to the last page you read.




To place a bookmark:

1. Tap anywhere on the screen to show the tool bar.
2. Tap  to mark the page. You can mark as many pages as you like.
3. To view the bookmarked pages, tap  > **Bookmark list** then tap the page that you want to open.


Annotating on the page

Annotating in your e-books allows you to see the definition of a word, copy a word or a phrase, share via e-mail, or listen through text-to-speech function.

Annotating a word



Annotating a phrase



To annotate a page:

1. Tap and hold the desired word until the action bar and the dictionary note are displayed.

NOTE: To select a phrase, tap and hold the word then slide your finger to select. When you select a phrase, the dictionary note does not appear.

2. From the action bar, choose from the following options:
 - a. Tap **Highlight** to mark a word or phrase.
 - b. Tap **Note** to record a word or phrase.
 - c. Tap **Text to Speech** to listen to the selected word or phrase.
 - d. Tap **Copy** to copy the selected word or phrase and paste it to a text app.
 - e. Tap **Share** to share a phrase then select an app that you want for sharing.


SuperNote

SuperNote is an easy-to-use app that lets you take notes, doodle, capture and insert photos, and record sounds and videos for a more interactive experience.

You can also share your notebooks via your ASUS WebStorage account.

To launch SuperNote, tap  on the Home Screen then tap  > **Enter**.

SuperNote main screen




Creating a new notebook

To create a new notebook:

1. Tap .
2. Name the file then select a template. The new note page appears instantly.



SuperNote Notebook interface



NOTE: The mode settings and notebook tool bar changes when you tap **Write** mode, **Type** mode or **Draw** mode.

Customizing your notebook

SuperNote allows you to be creative with your notebooks. From the tool bar, you can select several tools that lets you customize your notebooks.

NOTE: The settings of the tool bar may vary depending on the mode that you selected.

To customize your notebook:

1. In the SuperNote main screen, tap the notebook that you want to customize.
2. Tap **Write** to scribble on the page. Tap **Type** to use the keypad. Tap **Draw** to paint or draw on the page.

NOTES:

- For **Write** mode, tap **Baseline** on the notebook tool bar for penmanship guidelines when necessary.
 - For **Write** and **Type** modes, tap **Color** to select text color and **Bold** to select text weight.
 - For **Draw** mode, tap **Brush** to select stroke type, weight, opacity and color.
-
3. To insert text image and media files, tap **Insert** then tap the type of file that you want to insert.
 4. To move or resize an inserted object, tap **Select** then select the object that you want to move or resize.

SuperNote Read-only mode

To enable the Read-only mode, tap  then slide your finger up or down to view the pages of your notebook.



Renaming your notebook

To rename your notebook:

1. In the SuperNote main screen, tap and hold the notebook file then tap **Rename**.
2. Key in the the filename then tap **OK**.

Hiding your notebook

To hide your notebook:

1. In the SuperNote main screen, tap and hold the notebook file then tap **Lock to hide**.
2. Key in your password then tap **OK**.

NOTES:

- You will be prompted to key in a new password when you hide your notebook for the first time.
 - To view the hidden notebooks on the main screen, tap  then tap **Show locked notebook**.
-

Deleting your notebook

To delete your notebook:

1. In the SuperNote main screen, tap and hold the notebook file then tap **Delete**.
2. Tap **Delete** to confirm deletion of the notebook.

AudioWizard

AudioWizard allows you to customize the sound modes of your MeMO Pad for a clearer audio output that fits actual usage scenarios.

To launch Audio Wizard, tap  on the Home Screen then tap .



Using AudioWizard

To use AudioWizard:

1. In the AudioWizard window, tap the sound mode that you want to activate.

NOTE: Tap **OFF** if you want to deactivate any of the sound modes you previously saved.

2. Tap **OK** to save the selected sound mode and exit the AudioWizard window.

App Locker

App Locker is a security app that allows you to protect your private apps from unauthorized use. It asks for a password every time you launch a locked app.

App Locker also features file protection, allowing you to hide your private files and folders from unauthorized access.


Using App Locker

To use App Locker:


1. On the Home Screen, tap  then tap  .
2. Tap **Start**, set up your password then tap then **OK**.



3. Tap **OK** to activate App Locker.




App Locker screen



NOTES:

- The apps that you locked will appear as locked icons on the Home Screen and on the All Apps screen.
 - If you wish deactivate the App Locker, tap  then untick **Activate App Locker**.
-

File Protection screen



App Backup


App Backup allows you to back up your installed apps and data on your MeMO Pad or save it to an external storage device installed in your MeMO Pad. This app also restores your backed-up apps and data after updating your device's firmware.

To launch App Backup, tap  on the Home Screen then tap .

IMPORTANT!

- App Backup cannot restore apps that require an account authentication.
- If you want to duplicate your apps and data's backup files, ensure that you insert a microSD card in the microSD card slot before backing up your apps and data.

Backup List screen




Backing up your apps and data

To back up your apps and data:

1. On the App Backup main screen, tap **Backup List** on the left pane to view the list of installed apps and data.
2. Tick the apps that you want to back up, then tap .

- Key in the file name of your backup file, then tap **OK**.

NOTE: If you want to save a copy of your backup file, tick **Copy to backup file to:** then tap  to select folder.



- Set up a password for this backup file, then tap **OK**.




- Tap **OK** to proceed with the application backup.



- After the backup process is complete, tap **OK**.




Restore List screen



Restoring your apps and data

To restore your apps and data:

1. On the App Backup main screen, tap **Restore List** on the left pane to view the list of backup files.
2. Tap the file that you want to restore, then tap **OK**.




- Key in the password that you set up when you created the backup file, then tap **OK**.




- Select the file that you want to restore, then tap **OK**.



- Tap **OK** to proceed restoring the apps in your system.



- After the restoration process is complete, tap **OK**.



Widgets

Widgets allow you to conveniently access useful and fun applications on your MeMO Pad's Home Screen, serving as an app shortcut.

To view widgets, tap  on the Home Screen then tap **WIDGETS**.

Displaying a widget on the Home Screen

From the Widgets screen, scroll the screen sideways to select a widget. Tap and hold the selected widget, then drag it to the Home Screen.

IMPORTANT!

- You may be prompted to perform additional tasks such as registration or activation before you can use a selected widget.
 - If there is not enough space on the screen where you placed the widget, the widget will not be added to the screen.
-

Removing a widget from the Home Screen

From the Home Screen, tap and hold the widget until **X Remove** appears. Without lifting your finger, drag the widget to **X Remove** to remove the widget from your Home Screen.



Removes the widget from the Home Screen


ASUS Battery

ASUS Battery is a special widget designed to show the battery status of your MeMO Pad and its connected accessories by percentage and color.

To view ASUS Battery widget, tap  on the Home Screen then tap **WIDGETS**.

Displaying the ASUS Battery widget on the Home Screen

From the Widgets screen, scroll the screen sideways to look for ASUS Battery widget. Tap and hold the widget, then drag it to the Home Screen.



NOTE: You can also view your MeMO Pad's battery status in ASUS Quick Setting and notification area. For more details, refer to sections **ASUS Quick Setting** and **Notification panel**.

Appendices

Federal Communications Commission Statement

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by doing one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation on the 5.15-5.25 GHz frequency band is restricted for indoor use only. The FCC requires indoor use for the 5.15-5.25 GHz band to reduce the potential for harmful interference to co-channel Mobile Satellite Systems. It will only transmit on 5.25-5.35 GHz, 5.47-5.725 GHz and 5.725-5.850 GHz bands when associated with an access point (AP).

RF Exposure Information (SAR)

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels.

The highest SAR value for the device as reported to the FCC is 1.34 W/kg when placed next to the body.

The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: MSQK001.

Canada, Industry Canada (IC) Notices

This Class B digital apparatus complies with Canadian ICES-003 and RSS-210.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. The IC ID for this device is 3568A-K001.

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has been evaluated for and shown compliant with the IC Specific Absorption Rate ("SAR") limits when installed in specific host products operated in portable exposure conditions.

Canada's REL (Radio Equipment List) can be found at the following web address: <http://www.ic.gc.ca/app/sitt/relet/srch/nwRdSrch.do?lang=eng>

Additional Canadian information on RF exposure also can be found at the following web address: <http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf08792.html>

Canada, avis d'Industrie Canada (IC)

Cet appareil numérique de classe B est conforme aux normes canadiennes ICES-003 et RSS-210.

Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas causer d'interférence et (2) cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement. L'identifiant IC de cet appareil est 3568A-K001.

Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie émise par cet appareil sans fil est inférieure à la limite d'exposition aux fréquences radio d'Industrie Canada (IC). Utilisez l'appareil sans fil de façon à minimiser les contacts humains lors du fonctionnement normal.

Ce périphérique a été évalué et démontré conforme aux limites SAR (Specific Absorption Rate – Taux d'absorption spécifique) d'IC lorsqu'il est installé dans des produits hôtes particuliers qui fonctionnent dans des conditions d'exposition à des appareils portables.

Ce périphérique est homologué pour l'utilisation au Canada. Pour consulter l'entrée correspondant à l'appareil dans la liste d'équipement radio (REL - Radio Equipment List) d'Industrie Canada rendez-vous sur: <http://www.ic.gc.ca/app/sitt/reltel/srch/nwRdSrch.do?lang=eng>

Pour des informations supplémentaires concernant l'exposition aux RF au Canada rendez-vous sur: <http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf08792.html>

IC Warning Statement

The device could automatically discontinue transmission in case of absence of information to transmit, or operational failure. Note that this is not intended to prohibit transmission of control or signaling information or the use of repetitive codes where required by the technology.

The device for the band 5150-5250 MHz is only for indoor usage to reduce potential for harmful interference to co-channel mobile satellite systems; the maximum antenna gain permitted (for device in the bands 5250-5350 MHz and 5470-5725 MHz) to comply with the EIRP limit; and the maximum antenna gain permitted (for devices in the band 5275-5850 MHz) to comply with the EIRP limits specified for point-to-point and non point-to-point operation as appropriate, as stated in section A9.2(3). In addition, high-power radars are allocated as primary users (meaning they have priority) of the band 5250-5350 MHz and this radar could cause interference and/or damage to LE-LAN devices.

The Country Code Selection feature is disabled for products marketed in the US/ Canada. For product available in the USA/Canada markets, only channel 1-11 can be operated. Selection of other channels is not possible.

EC Declaration of Conformity

This product is compliant with the regulations of the R&TTE Directive 1999/5/EC. The Declaration of Conformity can be downloaded from <http://support.asus.com>.

Prevention of Hearing Loss

To prevent possible hearing damage, do not listen at high volume levels for long periods.



À pleine puissance, l'écoute prolongée du baladeur peut endommager l'oreille de l'utilisateur.

For France, headphones/earphones for this device are compliant with the sound pressure level requirement laid down in the applicable EN 50332-1:2000 and/or EN50332-2:2003 standard required by French Article L.5232-1.

CE Mark Warning



CE marking for devices wireless LAN/Bluetooth

This equipment complies with the requirements of Directive 1999/5/EC of the European Parliament and Commission from 9 March, 1999 governing Radio and Telecommunications Equipment and mutual recognition of conformity.

The highest CE SAR value for the device is 0.654 W/Kg.

This equipment may be operated in:

AT	BE	BG	CH	CY	CZ	DE	DK
EE	ES	FI	FR	GB	GR	HU	IE
IT	IS	LI	LT	LU	LV	MT	NL
NO	PL	PT	RO	SE	SI	SK	TR

DFS controls related to radar detection shall not be accessible to the user.

RF Exposure information (SAR) - CE

This device meets the EU requirements (1999/519/EC) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

The limits are part of extensive recommendations for the protection of the general public. These recommendations have been developed and checked by independent scientific organizations through regular and thorough evaluations of scientific studies. The unit of measurement for the European Council's recommended limit for mobile devices is the "Specific Absorption Rate" (SAR), and the SAR limit is 2.0 W/Kg averaged over 10 gram of body tissue. It meets the requirements of the International Commission on Non-Ionizing Radiation Protection (ICNIRP).

For next-to-body operation, this device has been tested and meets the ICNRP exposure guidelines and the European Standard EN 62311 and EN 62209-2. SAR is measured with the device directly contacted to the body while transmitting at the highest certified output power level in all frequency bands of the mobile device.

Power Safety Requirement

Products with electrical current ratings up to 6A and weighing more than 3Kg must use approved power cords greater than or equal to: H05VV-F, 3G, 0.75mm² or H05VV-F, 2G, 0.75mm².

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for detailed recycling information in different regions.

Regional notice for Singapore

Complies with
IDA Standards
DB103778

This ASUS product complies with IDA Standards.

Coating notice

IMPORTANT! To provide electrical insulation and maintain electrical safety, a coating is applied to insulate the device except on the areas where the I/O ports are located.

Proper disposal



Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



DO NOT throw the battery in municipal waste. The symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste.



DO NOT throw the MeMO Pad in municipal waste. This product has been designed to enable proper reuse of parts and recycling. The symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products.



DO NOT throw the MeMO Pad in fire. DO NOT short circuit the contacts. DO NOT disassemble the MeMO Pad.

Model name: K001 (ME301T)

Manufacturer:	ASUSTeK Computer Inc.
Address:	4F, No.150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN
Authorised representative in Europe:	ASUS Computer GmbH
Address:	HARKORT STR. 21-23, 40880 RATINGEN, GERMANY

EC Declaration of Conformity



We, the undersigned,

Manufacturer:	ASUSTeK COMPUTER INC.
Address, City:	4F, No. 150, LI-TE Rd., PEITOU, TAIPEI 112, TAIWAN
Country:	TAIWAN
Authorized representative in Europe:	ASUS COMPUTER GmbH
Address, City:	HARKORT STR. 21-23, 40880 RATINGEN
Country:	GERMANY

declare the following apparatus:

Product name :	ASUS MeMO Pad
Model name :	K001

conform with the essential requirements of the following directives:

☒2004/108/EC-EMC Directive

<input checked="" type="checkbox"/> EN 55022:2010	<input checked="" type="checkbox"/> EN 55024:2010
<input checked="" type="checkbox"/> EN 61000-3-2:2006+A2:2009	<input checked="" type="checkbox"/> EN 61000-3-3:2008
<input type="checkbox"/> EN 55013:2001+A1:2003+A2:2006	<input type="checkbox"/> EN 55020:2007+A11:2011

☒1999/5/EC-R & TTE Directive

<input checked="" type="checkbox"/> EN 300 328 V1.7.1(2006-10)	<input checked="" type="checkbox"/> EN 301 489-1 V1.9.2(2011-09)
<input checked="" type="checkbox"/> EN 300 440-1 V1.6.1(2010-08)	<input checked="" type="checkbox"/> EN 301 489-3 V1.4.1(2002-08)
<input checked="" type="checkbox"/> EN 300 440-2 V1.4.1(2010-08)	<input type="checkbox"/> EN 301 489-4 V1.4.1(2009-05)
<input type="checkbox"/> EN 301 511 V9.0.2(2003-03)	<input type="checkbox"/> EN 301 489-7 V1.3.1(2005-11)
<input type="checkbox"/> EN 301 908-1 V5.2.1(2011-05)	<input type="checkbox"/> EN 301 489-9 V1.4.1(2007-11)
<input type="checkbox"/> EN 301 908-2 V5.2.1(2011-07)	<input checked="" type="checkbox"/> EN 301 489-17 V2.1.1(2009-05)
<input checked="" type="checkbox"/> EN 301 893 V1.6.1(2011-11)	<input type="checkbox"/> EN 301 489-24 V1.5.1(2010-09)
<input type="checkbox"/> EN 300 330-1 V1.7.1(2010-02)	<input type="checkbox"/> EN 302 326-2 V1.2.2(2007-06)
<input type="checkbox"/> EN 300 330-2 V1.5.1(2010-02)	<input type="checkbox"/> EN 302 326-3 V1.3.1(2007-09)
<input checked="" type="checkbox"/> EN 62311:2008	<input type="checkbox"/> EN 301 357-2 V1.4.1(2008-11)
<input checked="" type="checkbox"/> EN 62209-2:2010	<input type="checkbox"/> EN 50385:2002
<input checked="" type="checkbox"/> EN 62479:2010	<input type="checkbox"/> EN 62311:2008

☒2006/95/EC-LVD Directive

<input type="checkbox"/> EN 60950-1 / A11:2009	<input type="checkbox"/> EN 60065:2002 / A2:2010
<input checked="" type="checkbox"/> EN 60950-1 / A12:2011	<input type="checkbox"/> EN 60065:2002 / A12:2011

☒2009/125/EC-ErP Directive

<input type="checkbox"/> Regulation (EC) No. 1275/2008	<input checked="" type="checkbox"/> Regulation (EC) No. 278/2009
<input type="checkbox"/> Regulation (EC) No. 642/2009	

☒2011/65/EU-RoHS Directive

Ver. 121001

☒CE marking



(EC conformity marking)

Position : **CEO**

Name : **Jerry Shen**

Declaration Date: Dec. 14, 2012

Year to begin affixing CE marking:2012

Signature : _____

